FLOOR LAMP

SUNPENTOWN®

SL-810

SL-820

EasyEye™

© 2003 Sunpentown

INSTRUCTION MANUAL

1 ASSEMBLE EASY EYE FLOOR LAMP

1. Remove all parts from box. Carefully read all instructions and locate parts for assembly.
2. Set lamp base on sturdy ground, with the shaft facing the same direction as the base(the side with the power switch and front indication at the bottow should face front), connect the connectors between the shaft and base(1).
3. Insert shaft into base until the indicating curve line (located at the bottom of the shaft) is covered and a clicking sound is heard.
4. Connect the connectors between the lamp head and shaft(2).
5. Insert bottom of gooseneck into shaft until it clicks into place



2 TO REMOVE THE COMPACT FLUORESCENT BULB

1. Make sure the lamp's power is switched OFF and power cord is unplugged.
2. Remove the Anti-reflective Lens by pushing the clip on the edge of the lens and pull.
3. Using a slotted (flat) screwdriver, insert the tip scredwriver into the small indent located between the bulb and the socket. push up gently to pop the bulb from the socket.
4. Firmly hold base (2) and pull defective bulb (3) from the socket (1) in an upward motion (away from socket),
5. Remove bulb from clips by pushing the clips outward.



3 TO INSTALL THE COMPACT FLUORESCENT BULB

1. Make sure the lamp's power is switched OFF and power cord is unplugged.
2. Remove the Anti-reflective Lens by pushing the clip on the edge of the lens and pull.
3. Firmly hold at base (2), insert bulb (3) into clips and push firmly into socket (1).
4. Be sure it is firmly seated in the socket and snapped into the bulb clip (4).
5. Replace the Anti-reflective Lens.



4 TO OPERATE

Model Number SL-810 :Turn on the switch, the unit will light up immediately and generates negative ions to help balance the ionization in your home and office.



Model Number SL-820 :Turn on the swich, the unit lights up immediately.

5 CAUTION

Do not dismantle.
Do not place near flammable items or high heat sources.
Do not bend, pull or manipulate the power cord.
Keep away from moisture.

6 SPECIFICATION

Model	SL-810/SL-820
Power Consumption	27W
Power Supply	120V/60Hz
Dimensions(INCH)	48(H)x9(W)x10(L)
Weight	10.3LBS
Compact Fluorescent Bulb	ML27W

** Compact Fluorescent Bulb can be purchased directly from Sunpentown. Please call 1-800-330-0388 or email order@sunpentown.com

EASYEYE FLOOR LAMP

By Sunpentown

Your Guarantee

If this product is found to be faulty as a result of faulty materials or workmanship within one year from date of purchase, it will be repaired or replaced free of charge. Parts are covered for three years.

This guarantee is subject to the following terms:

Sunpentown, must be notified of the fault.

Proof of purchase must be presented to Sunpentown's nominated representative.

The warranty will be void if the product is modified, misused or repaired by an unauthorized person.

The guarantee after repair or replacement will not be extended beyond the original one year period.

All replacement parts or units will be new or reconditioned.

Parts or units, which are replaced, become the property of Sunpentown.

The warranty applied for the use of the product in the USA

Warranty does not include freight charges.
Warranty void if used with light bulbs other than Sunpentown light bulb.

Sunpentown International Inc.
18249 Valley Blvd.
City of Industry, CA 91744
Note: For Service, please call: 1-800-330-0388 or visit www.sunpentown.com

This GRARANT EE is in addition to your Statutory Rights.

Dear Customer: Please keep this warranty for your record. DO NOT return it